



Original

Installation And Service Manual

FOUR POST PARKING LIFT Model: 407-P

Cargo Claims

If there is any missing or damaged product during transportation, the buyer must note on the shipping paperwork or refuse the shipment.

NOTATE ALL DAMAGE OR REFUSE
DAMAGED SHIPMENT!

DANGER

Read the entire contents of this manual before using this product. Failure to follow instructions and safety precautions could result in serious injury or even death. Make sure all other operators also read this manual. Keep this manual near the machine so that it can be seen by all users. By proceeding with installation and operation, you agree that you are fully understand the contents of this manual and take full responsibility for the use of the product.

CONTENTS

PROFILE.....	1
IMPORTANT SAFETY INSTRUCTIONS.....	3
I. PRODUCT FEATURES AND SPECIFICATIONS.....	5
II. STORAGE AND INSTALLATION REQUIREMENT.....	7
III. INSTALLATION STEPS.....	9
IV. EXPLODED VIEW.....	30
V. TEST RUN.....	36
VI. OPERATION INSTRUCTIONS.....	37
VII. MAINTENANCE SCHEDULE.....	38
VIII. TROUBLE SHOOTING.....	39
IX. CAR LIFT SAFETY TIPS	40
X. LIFT DISPOSAL	40

Explanation of the safety warning symbols used in this manual

 DANGER Risk of death or injury

 WARNING Dangerous or unsafe practices that may result in death or injury

 CAUTION Dangerous or unsafe practices that may result in personal injury, product damage or property damage

ATTENTION Conditions that may result in damage to products or property

PROFILE

This installation and service manual is specially prepared for you. Your new lift is the product of over a decade of continuous research, testing and development and is the most technologically advanced lift on the market today.

Please make sure to read through this manual before operating the lift.

Record the information on the nameplate label here:

Model No.: _____

Serial No.: _____

Manufacturer date: _____

WARRANTY

The warranty period for the steel structure part of new car lift is 5 years, hydraulic components, bronze bushings, slider blocks and plastic parts are under warranty for 3 years, electrical components and cables warranty for 2 year. Rubber pads are without warranty. During the warranty period, the manufacturer will repair or replace the defective parts free of charge including shipping costs.

This warranty does not cover damage caused by normal wear and tear, improper use, damage in transit, or damage caused by lack of maintenance.

This warranty is unique and supersedes what is expressed and implied in all other warranties. The manufacturer shall not be liable for any particular, indirect or accidental damage resulting in breach of or delay in the execution of the warranty. The manufacturer reserves the right to design and improve the product and has no obligation to make notice of the changes in advance.

The product warranty based on the above clause is based on the model number and serial number of the equipment. This information must be provided in conjunction with all warranty information at the time of service and warranty.

SAFETY WARNING LABEL



Fig.1

IMPORTANT SAFETY INSTRUCTIONS

In order to properly maintain your product and ensure operator safety, it is the responsibility of the product owner to read and follow these instructions!

1. Ensure product installation full complies with all applicable local and national rules, ordinances and regulations;
2. Ensure that all operators are properly trained, know how to operate the unit safely, and are properly supervised;
3. Do not operate the lift until you are sure all parts are in place and operating correctly;
4. Keep your hands and feet away from the machine. Keep hands and feet away from any moving parts. Keep your feet away from the lift as it descends and avoid pressing on pointed objects;
5. Keep the work area clean. A cluttered workspace can lead to injuries;
6. The machine is only approved for indoor installation and use. Outdoor installation is prohibited;
7. Only trained operators are allowed to handle the lift machine. All untrained persons must stay away from the workplace. Never allow untrained persons to handle or operate the machine;
8. Use the lift properly. Use the lift in the correct way;
9. Warning! Keep persons and objects from the lift when lifting the a vehicle;
10. If the vehicle is at risk of falling, make sure no one is around the lift;
11. Before preparing to approach or service the vehicle, ensure that the safety device is in effect;
12. Dress appropriately when operating machines, and consider wearing non-slip steel-toe shoes for safety;
13. Beware of electric shock. In order to protect the operator from electric shock, the lift in use must be grounded. Do not connect the green wire to the terminal. This is the ground wire;
14. Danger! The power supply used in this type of lift has high voltage. Please disconnect the power supply before any circuit repair. Unplug in case the power supply is accidentally switched on during maintenance;
15. Warning! There is a risk of explosion. There are parts in the equipment that produce arc light and spark. Do not operate near flammable gas. This machine should not be placed in the lounge or basement;
16. Maintain with care. Keep the machine clean for better and safer operation. Perform

proper lubrication and maintenance procedures according to the manual. Keep handles or buttons clean, dry, and free of oil;

17. Stay alert. Use common sense to observe what you are doing and stay alert;
18. Check for damaged parts. Check for adjustments to moving parts, damage to parts, or anything that may affect their operation. Do not use the machine if the parts are damaged;
19. Do not remove relevant safety parts from the machine. Do not use a lift if it is damaged or missing;
20. Operate the lift only at temperature between 5°C to 40°C (41°F to 104°F).



DANGER Be very careful when installing, operating, maintaining or repairing this equipment. Failure to comply may result in property damage, product damage, injury or (in very rare cases) death. Ensure that only authorized personnel operate the equipment. All repairs must be carried out by an authorized technician. Do not modify the machine, this voids the warranty and increases the probability of personal injury or property damage. Ensure to read and follow this instructions on the label.

I. PRODUCT FEATURES AND SPECIFICATIONS

407-P FEATURES

- Single-cylinder drive and cable transmission.
- Single-point manual safety release enhances the convenience and reliability of descent operations.
- Both automatic mechanical primary safety device and cable-slack secondary safety device are equipped for enhanced security.
- Optional: Rolling jacks, caster kits
- Non-skid diamond platforms and adjustable safety lock ladders.




Fig. 2

Dimension




Fig. 3

SPECIFICATION

Model	Lifting Capacity	Lifting Time	A	B	C	D	E	
			Overall Length (Inc. Ramps)	Overall Length (Without Ramps)	Overall width	Width between posts	Max. Lifting Height	Max. Locking height
407-P	7000lbs	83s(110v)/31s(220v)	185 7/8"	152 5/8"	94 7/8"	85 3/8"	73 7/16"	70 11/16"

F	G	H		I	J	K	Motor
		Max. height underneath runway	Max. Locking height underneath runway				
82 7/8"	4 15/16"	69 1/2"	66 3/4"	77"	37"	74 3/8"	1.0HP/110V 2.0HP/220V

⚠Warning When driving the vehicle into the lift, make sure it is positioned in middle of either group of runways. Any hit of the lift could result in damage to either the vehicle or lift.

II. INSTALLATION REQUIREMENT

A. TOOLS REQUIRED

✓ Rotary Hammer Drill (Φ19)



✓ Hammer



✓ Level Bar



✓ Adjustable Spanner (12")



✓ Wrench set

(10#, 13#, 14#, 15#, 17#, 19#, 24#, 27#, 30#)



✓ Ratchet Spanner With Socket (28#)



✓ Carpenter's Chalk



✓ Screw Sets



✓ Tape Measure (7.5m)



✓ Pliers



✓ Lock wrench



✓ Socket Head Wrench (3#, 5#, 8#)



Fig. 4

B. Equipment storage and installation requirements.

- 1 . Store the equipment in a dry, non-moldy, non-flammable environment.
- 2 . The lift is generally approved for indoor installation and use. If need outdoor installation, the optional motor protect cover is required. (Kits No.: 40810)
- 3 . When installing the device, take safety precautions according to the instructions to avoid device damage.
- 4 . During installation, all parts should be fastened to ensure the stability and smooth operation of the machine.
- 5 . After installation, the whole machine should be checked to make sure that every component is working properly.

C. The equipment should be unloaded and transferred by forklift.




Fig.5

D. SPECIFICATIONS OF CONCRETE (See Fig. 6)

Specifications of concrete must be adhered to the specification as following.

Failure to do so may result in lift and/or vehicle falling.

1. Concrete must be thickness 4" minimum and without reinforcing steel bars, and must be dried completely before the installation.
2. Concrete must be in good condition and must be of test strength 3000psi minimum. Solidify at least 15 days.
3. Floors must be level and no cracks.




Fig. 6

E. POWER SUPPLY

1. You are required to use a licensed and qualified electrician for the installation process.
2. The power supply capacity must be more than 2.0HP, with a cord larger than 12AWG, and must be properly grounded.




DANGER All electrical wiring must be performed by a licensed and certified electrician. Attempting to connect the circuit without proper certification may result in damage to the lift or electrocution, resulting in serious injury or death.

III. INSTALLATION STEPS

A. Location of installation

1. Installation space: Ensure there is enough space for the lift. Accurately measure the front, back, side and top mounting dimensions and refer to the below figure data .
2. Overhead obstacle: Check for overhead obstacles, such as building supports, heaters, lights, wires, and low ceilings, etc..
3. Installation: The lift is only approved for indoor installation and use, and outdoor installation is prohibited.
4. Floor: Install lift only on flat concrete floor. Do not install on asphalt or any other surface.



⚠ CAUTION Installing the lift on a surface with slopes more than 3° could lead to injury or even death. This lift is designed for installation on a flat and level surface only. (Defined as no more than 10mm difference over the installation area). If the floor cannot be leveled, consider changing installation locations.

B. Check the parts before assembly.

1. Packaged lift and hydraulic power unit (**See Fig. 8**).



Fig. 8

2. Move the lift aside with a fork lift or hoist, open the package and check the parts according to the shipment list. (**See Fig. 9**).




Fig. 9

3. Move the columns and cross beams aside to the installation position. (**see Fig 10**)




Fig. 10

4. Loose the screws of the upper package stand, take off the off side platform, take out the parts inside the power side platform, then remove the package stand.
5. Move aside all the parts to the installation position and check the parts according to the parts list (**See Fig. 11**).




Fig. 11

6. Check the parts of parts box according to the parts box lift . (See Fig. 12).




Fig. 12

7. Check the parts of the parts bag according to the parts bag list (See Fig. 13).



Fig. 13



C. Use a carpenter's chalk line to establish installation layout (see Fig 14).

Place the posts according to the installation dimension.

Note: Reserve space front and behind the installation site.




Fig.14

MODEL	A	B	C
407-P	152 5/8"	94 7/8"	179 5/8"

D. Install cross beams (See Fig.15, Fig.16).





Fig.15



E. Install the Safety ladders.

1. Take off the cross beam protective cover and remove one nut of the safety ladder, adjust the other nuts of four safety ladders to be at the same position. Then install the safety ladders (See Fig. 17).




Fig.17

2. Install safety ladders (See Fig. 18).




Fig. 18

F. Put the cross beams at the same height and lock on the safety ladders (See Fig. 19).




Fig. 19

G. Install power side platform.

1. Install the power side platform on the cross beams by a forklift or manually, offset the cross beams leaning outward until the pulleys of both platforms can enter into the cross beam windows (**See Fig.20**), align holes on the power side platform and cross beam, then screw up the bolts.




Fig. 20

2. Install connecting bolts of tire stop and platforms: Tighten cross beam B and platform with round head socket bolts, tighten cross beam A, platform and tire stop plate with hex bolts. (Note: Tire stop plate should be installed at the front direction. Hex bolts are used for tire stop plate, and the round head socket bolts are for the other side), **See Fig.21**

Notice: The lift is designed for drive-in from either direction of cross beams. The diagram below shows the drive-in direction from cross beam B. If driving in from cross beam A direction, make sure the tire stop plate is installed on cross beam B with hex bolt. Install the power unit accordingly and place the control handle on the same side as the power unit.




Fig. 21

H. Install offside platform and limit slider (See Fig. 22).






Fig. 22


I. Install safety device connecting rod, release handle and coupling sleeve.



1. Install safety device connecting rod and release handle, see fig 23



⑤ Install extended release handle and pull rope.



2. Install coupling sleeve

2.1, Coupling sleeve installation illustration when power side column is in the position as shown below. See fig 24.




Fig. 24

② Align the holes that connecting the connecting rod and coupling sleeve as show above, tighten with M8*20 screw with lock washer.

Note: There should be 1 to 2mm clearance between the screw head and the coupling sleeve after tighten the screw.

2.2, Coupling sleeve installation illustration when power side column is in the position as shown below. See fig 25





Fig. 25

J.Illustration for cable installation


1. Pass through the cables from the platform to the columns according to the number of the cables (See Fig. 26).



Make sure the cable connecting sleeve step is in the hole while the cables is tensioned.

NO. Cable	①	②	③	④
407-P Length (inc. cable fitting)	168 5/16"	376"	224"	320 1/16"

2. Pass The cables through the cross beam to top plate of columns and screw with cable nuts (See Fig. 27).



3. The sketched overview of cables finally installed under platform. (See Fig. 28).




Fig. 28

4. Install tension spring and cross beam protective cover. **(See Fig. 29).**




Fig. 29

K. Install power unit

Fixing the motor installing plate to the power side column. And install the power unit to the installing plate. See fig 30.




Fig. 30

L. Install Hydraulic System

1. For power unit installed to the column that connected to cross beam A (See Fig. 31)

Note: Oil hoses connected to oil cylinder must be passed above the cable and cylinder inlet port should be upward a little to avoid the oil hose scratched by cable.






Fig. 31


Pass oil hoses, oil return hoses outside the platform through the bellow pipe, then connect to the power unit.

M. Install the anchor bolts.

1. Check the plumbness of columns with leveling instrument and adjusting with the shims.




2. Prepare the anchor bolts (See Fig. 33).




3. Use the prescribed rotary hammer drill, drill all the anchor holes and install the anchor bolts and tighten all nuts. (See Fig. 34)

Note: The tightening torque for the anchor bolt is 150N.m ,anchor bolts should be driven into the ground at least 3 1/2".



N. Install foldable drive-in ramp ass., jack tray and plastic oil tray.

Install the M16*30 bolts into the cross beam according to the below diagram, then hang the 4 units foldable drive-in ramps assy. on the bolts. See fig 35.



Fold up the front half of ramps after the car is parked well.

Exploded view of foldable drive-in ramps assembly




Fig. 36

Parts List of foldable drive-in ramps assembly (1104543020C-01)

No.	Part Number	Description	Qty.
6-1	1104543020A-01	Foldable drive-in ramps #1	2
6-2	1104533026A-01	Foldable drive-in ramps #2	2
6-3	1104543021	Connect pin	4
6-4	10209010	φ10 Clip ring	8

O. Install Electrical System

Connect the power source according to the data plate of Motor.

Note: For the safety of operators, the power wiring must contact the floor well.

Single phase motor

Connect the two power supply wire (hot wire **L1** and **L3**) to terminals of AC contactor marked **L1**, **L3** respectively. Connect the earth wire to earth strip.

Note: if the local power are with 2 live wires, connect them to L1, L3 terminal of AC contactor respectively.




Fig. 37

DANGER All electrical wiring must be performed by a licensed and certified electrician.

Before ensuring the main power has disconnected from the lift and cannot be re-applied until all procedures have been completed, do not perform any maintenance or installation to the lift.

DANGER Do not use the lift if the wires are damaged or severely worn. If the vehicle rises without noticing damage or extreme wear, carefully lower the vehicle to the ground. Once the lift is on the ground, remove it, disconnect the power, and arrange for protection.

IV. EXPLODED VIEW

Model 407-P




Fig. 38

Power-side platform




Fig. 39

PARTS LIST FOR MODEL 407-P

Item	Part No.	Description	Qty.
1	11410001-02	Power-side Column	1
2	1104542001C-01	Cross Beam A assy.	1
3	11410002-02	Offside Column	3
4	1104543001B	Offside Platform	1
5	1104542001D-01	Cross Beam B assy.	1
6	1104543020C-01	Folding Drive-in ramp	2
7	1004574011	Hex Bolt M8*20 (with washer, spring washer and Outer hexagon nut)	2
8	11423004	Cylinder fixed ring	1
9	C804400	Cylinder	1
10	1104533013A-01	Piston rod connecting seat	1
11	1104543001A	Power-side Platform	1
12		Manual Power Unit	1
13	11420243	Straight Fitting for cylinder	1
14	C802003	Flow Compensation Valve	1
15	11420245	Straight Fitting	1

Item	Part No.	Description	Qty.
16	10201020	90°degree fitting	1
17	1104543009A	Pulley pin	4
18	1104543016	Adjusting sleeve of pulley	1
19	1004542002	Bronze bush for pulley	10
20	1104543011	Pulley	6
21	10481005	Washer 1 3/16"	23
22	1002735012	Hex Bolt M8*16 (with washer, spring washer)	6
23	1104533017A-01	Pulley Pin	2
24	1104533024	Pad tube	2
25	10620141	Bronze bush	2
26	1104543017	Pulley	2
28	33101362	Socket Bolt M10*75	1
29	10640109	Washer	1
30	10410012	Hex Nut M24	1
31	10201005	Split Pin φ4*50	1
32	1004543006	Slider block	1
33	1004544010	Socket Bolt M8*15 (with washer, spring washer)	2
34	85090099	Socket Bolt M10*90	4
35	10420175A	Hex nut M20	8
36	11410022	Safety ladder	4
37	1004544011	Cup Head Bolt M16*30 with Wahser	4
38	1004574016	Hex Bolt M16*35 (with washer, spring washer)	4
39	11410015-1	Tire stop plate	2
40	1004574017	Hex Bolt M12*20 (with washer, spring washer)	4
41	10410016A	Plastic block	16
42	1004574018	Socket Bolt M8*40 (with washer, self-locking nut)	16
43	11410024-01	Connecting tube	1
44	1104542009	Connecting bar for safety device L=70 1/2"	2
45	1004574019	Socket Bolt M8*35 (with spring washer)	4
46	10217005	Plastic ball M10	1
47	10209056	Self locking Nut M10	1
49	11410100	Extension lock release handle	1
50	10409702001A	Safety release handle	1
51	10420043	Socket Bolt M8*20	2
52	1004543003	Cable ① L=168 5/16"	1
53	1004543004	Cable ② L=376"	1
54	1004543002	Cable ③ L=224"	1
55	1004543001	Cable ④ L=320 1/4"	1
56	10209066	Hex nut M16	8
57	1104541002	Adjusting sleeve of cable	4
58	1104541001	Cable gasket	4
59	10209145A	Cup head bolt with washer M6*12	8
60	1104542012	Cover for cross beam	4
61	1104551003	90 degree installation plate	1
62	1004574011	Hex Bolt M8*20 (with washer, spring washer, hex nut)	4
63	1002215009	Hex Bolt M8*30 (with washer, rubber ring, self-locking nut)	4
64	10420166	90 degree fitting	1

Item	Part No.	Description	Qty.
65	1004543007	Oil return hose L=195 3/8"	1
66	1004543005	Oil hose	1
67	10420120	Extend straight fitting with nut	1
68	1004544006-01	Oil hose L=44 1/16"	1
69	10209060	90 degree Fitting for power unit	1
70	10420095	Straight fitting	1
71	1004533010	Bellows pipe L=43 5/16"	1
72	10201090	Shim(1mm)	20
	10620065	Shim(2mm)	20
73	10209059	Anchor bolt 3/4*5-1/2	16
74	10410013	Hex Bolt M16*30	4
75	1004544009	Parts box	1
76	40816	Adjustable Jack tray (Optional part)	1
77	40806	Plastic oil tray (Optional part)	1

4.1 CYLINDERS EXPLODED VIEW C804400 (Old code 1004546000-01)




Fig. 40

Parts List

Item	Part No.	Description	Qty.
9-1	10420059	Dust ring	1
9-2	1004016001	Y- Ring USH	1
9-3	11420061	End cover	1
9-4	10420062	O- Ring	1
9-5	1004546001A-01	Cylinder components	1
9-6	1104546002-01	Piston Rod	1
9-7	11420065	Cylindrical pin	1
9-8	10420066	Support Ring	1
9-9	10420067-01	Y- Ring USH	1
9-10	11420068	Piston	1

4.2 CROSS BEAM ASSY. EXPLODED VIEW 1104542001C-01




Fig.41

Parts For cross beam

Item	Part No.	Description	Qty.
2-1	10206032	Snap Ring $\varphi 25$	2
2-2	1004574013	Hex Bolt M8*20 (with washer, self-locking nut)	4
2-3	1104542008-01	Connecting bar for safety lock	2
2-4	1104572003A	Safety lock rotated device assy.	2
2-5	1104542011A-01	Connecting bar assy. for safety lock	2
2-6	1004574014	Hex Bolt M8*25 (with washer, self-locking nut)	4
2-7	1104542006-01	Pulley pin 1 3/16" * 3 15/16"	4

2-8	1104542010	Pulley 4 17/32" * 5/8"	4
2-9	1104542007	Pulley pin sleeve 1 9/16" * 2 1/32"	4
2-10	10410146	Spring 9/16" * 3/32" * 2 15/16"	4
2-11	11420174	Spacer	4
2-12	10420035	Tension pulley	4
2-13	10209010	Clip ring φ10	4
2-14	10206019	Clip ring φ19	24
2-15	11420171	Pin 3/4" * 3 7/8"	12
2-16	11420175	Slack-cable safety lock (Left & Right)	2 each
2-17	11420172	Pin Bush For Slack-cable safety lock 31/32" * 1/8" * 1 7/32"	8
2-18	10410099	Spring 9/16" * 3/32" * 3 15/16"	2
2-19	1004542001	Spring 9/16" * 3/32" * 1 31/32"	4
2-20	11420038	Pin 5/8" * 3 7/8"	8
2-21	10420037	Snap ring φ16	16
2-22	1002735009	Socket Bolt M6*16 (with washer, spring washer)	8
2-23	11420044	Stop block	4
2-24	1104542001B-01	Cross Beam	2

4.3 Illustration of hydraulic valve for power unit




Fig.42

V. TEST RUN

1. Fill the oil tank with around hydraulic oil (in order to ensure the service life of the hydraulic system and ensure the best condition of the equipment, please fill in #46 high-quality anti-wear hydraulic oil).
2. Press the power unit button, until the four cables are tightened. Check the coordination between the cables and the pulleys, the cables **SHALL NOT** cross or fall out of the pulley.
3. Press the power unit release handle to lock the cross beam on the safety ladder. Adjust the safety ladder nuts to make sure the platforms at same level. Then tighten both the top and bottom nuts of safety ladder.
4. Balance the tension of cables by adjusting the cable nuts. It is a must to run several cycles up/down of the lift when performing synchronization operation.
Make sure all four safety locks can be locked/released at the same time, then tightened all the cable nuts.
5. Make sure the cross beam slide blocks and columns are clearance fit, that the slider blocks can slide smoothly with the column. DO NOT tighten the slider blocks.
6. After all above adjustments finished, take the loading test. Firstly low-level load test are taken several times to check the synchronization of operation and all safety locks. If they are no other abnormal phenomena, then take the full cycle load tests several times, otherwise repeat the above adjustments.

Circuit Diagram of Hydraulic System




Fig.43

VI. OPERATION INSTRUCTIONS

To lift vehicle

1. Keep clean of site near the lift;
2. Drive in the vehicles on platforms and apply the parking brake.
3. Fold up the front half of drive-in ramps.
4. Power on, push the power unit UP button, lift the vehicles to the working position.

Note: Make sure the vehicles are in steady safe status.

5. Press the power unit release handle, the lift goes down and be locked. Check and make sure the lift is locked at the same level locks .

 **WARNING** It is unsafe to work when the lift without locking at safety device after it has been raised. The vehicle may fall, potentially causing damage the vehicle and lift, even causing injury or death to someone nearby.

 **WARNING** AMGO recommends using provided anchor bolts for maintenance or service. If not using anchor bolts, ensure each column is plumb before lifting on level surface.

To lower vehicle

1. Clear obstructions around and under the lift and keep people away from the lift.
2. Push power unit **UP** button to raise the lift 3-5 seconds, then the safety lock is out of lock status. Pull the release handle, make sure the safety lock released, press the power unit release handle, the lift will start to lower.
3. Lower the lift to the lowest position, unfold the front half of drive-in ramps, and drive away the vehicles
4. Turn off the power.

VII. MAINTENANCE SCHEDULE

Monthly:

1. Lubricate cables.
2. Make visual inspection of cables for possible wear or damage.
3. Make visual inspection of hydraulic hoses for possible wear or leakage.
4. Lubricate all rollers, pins and safety devices with 90WT gear oil.

Every six months:

1. Make a visual inspection of all moving parts for possible wear, interference or damage.
2. Check and adjust as necessary, cable tension to ensure synchronization.
3. Check columns for plumbness.

Oil cylinder maintenance:

In order to extend the service life of the oil cylinder, please operate according to the following requirements.

1. Recommend to use N46 anti-wear hydraulic oil.
2. The hydraulic oil of the lifts should be replaced regularly during using. Replace the hydraulic oil 3 months after the first installation. Replace the hydraulic oil once a year afterwards.
3. Make at least one full trip raising and lowering per day. For exhausting the air from the system, which could effectively avoid the corrosion of the cylinder and damage to the seals caused by presence of air or water in the system.
4. Protect the outer surface of the oil cylinder's piston rod from bumping and scratching, and timely clean up the debris on the oil cylinder dust-ring and the piston rod.

⚠ DANGER

Make sure the lift is completely disconnected from the power source before maintenance. If there is any external electrical lock/shutdown device, make sure to implement them before maintenance. The contact with high voltage/current, may cause injury or even death.

VIII. TROUBLE SHOOTING

TROUBLE	CAUSE	REMEDY
Motor does not run	1. Start Button does not work 2. Wiring connections are not in good condition 3. Motor burned out 4. AC contactor burned out	1. Replace start button 2. Repair all wiring connections 3. Repair or replace motor 4. Replace AC contactor
Motor runs but the lift is not raised	1. Release valve in damage 2. Gear pump in damage 3. Relief valve or check valve in damage 4. Low oil level	1. Repair or replace 2. Repair or replace 3. Repair or replace 4. Fill tank
Lift does not stay up	1. Release valve out of work 2. Relief valve or check valve leakage. 3. Cylinder or fittings leaks	Repair or replace
Lift raises too slow	1. Oil line is jammed 2. Motor running on low voltage 3. Oil mixed with air 4. Pump leaks 5. Overload lifting	1. Clean the oil line 2. Check electrical system 3. Fill tank 4. Repair or replace pump 5. Check load
Lift cannot lower	1. Safety device are not in activated 2. Release valve damaged	1. Operate again 2. Repair or replace

⚠WARNING A lift would be dangerous if operated by inexperienced or distracted operators. Operators should be fully aware that lifting a vehicle is a potentially life-threatening operation, especially if ignoring the mandatory safety precautions.

IX. CAR LIFT SAFETY TIPS

Put this safety tips in a place where you can always alert the operator. Please reference to the lift manufacturer's manual for specific information about the lift.

1. Check the lift daily. If the machine breaks down or has damaged parts, do not operate, and use original equipment parts to repair.
2. **Do not** overload . The rated weight of the manufacturer design is indicated on the label of the lift.
3. Position control of the vehicle and operation of the lift can only be done by a trained and authorized person.
4. **Do not** lift a car with occupants inside. Keep the customers or bystanders away from the lift.
5. Keep the area around the lift free of obstacles, lubricating oil, grease, garbage and other debris for a long time.
6. Carefully drive the vehicle onto the lift and lifting up to the required height for operation.
Noted: lift it high enough if you are working underneath, and make sure the safety devices are locked.
7. **Noted:** removing(install) parts from(to) a vehicle would cause a sudden shift of gravity which may result in instability of the vehicle. Please refer to the vehicle manufacturer's service manual as a recommended procedure if you need remove/install parts from(to) the vehicle
8. Before lowering the lift , make sure all obstacles underneath, include tool tray, tool rack etc., are all removed.

X. LIFT DISPOSAL

When the car lift cannot meet the requirements for normal use and needs to be disposed, it should follow local laws and regulations.

**Address:**

SC Division: 1931 Joe Rogers Jr Blvd, Manning, SC 29102, USA

TX Division: 4310 Adler Dr., Suite #200, Dallas, TX 75211, USA

<http://www.amgohyd.com>

Manual No.: 72248003
Revision Date: 2025/11