

AMGO® Hydraulics

Original

Installation And Service Manual



Portable Low-rised scissors lift
Model:LR06

CONTENTS

Product Features and Specifications	1
Installation Requirement	2
Step of Installation	3
Exploded View	7
Operation Instructions	13
Maintenance Schedule	14
Trouble Shooting	15
Lift disposal	15

I. PRODUCT FEATURES AND SPECIFICATIONS (See Fig.1)

PORTABLE LOW-RISED MODEL LR06

- Self-locking safety device: 3 stage safety lock, mechanical lock, automatic release.
- Portable unit is easy to move with the power unit stand
- High speed: From 0-23 5/8" just 21 seconds
- Standard rubber pads included



Fig.1

MODEL LR06 SPECIFICATIONS

Model	Lifting Capacity	Raised Height	Lifting Time	Overall Length	Overall Width	Lowered Height	Runway Width	Runway Length	Motor
LR06	6000lbs	23 5/8"	21S	76 1/4"	70"	4 1/8"	18"	53 1/4"	1.0 HP Single Phase

II. INSTALLATION REQUIREMENT

A. Tools requirement

✓ Screw Set



✓ Socket Head Wrench (8")



✓ Wrench sets: (13#, 15#, 17#, 19#)



✓Grease gun



✓Pliers



Fig.2

B. Power requirement

The electrical source must be 1.0HP minimum. The source cable size must be 2.5mm² and in good condition of contacting with floor.

III. STEPS OF INSTALLATION

A. Check the parts before assembly, make sure all the parts are completed.

1. Packaged lift, Parts box, Power Unit and Power Unit Stand.

Move aside the parts, Open the outer packing and check the parts according to the shipment parts list (**See Fig. 3**).




Fig. 3

2. Open the parts box, check the parts according to the part list (**See Fig. 4**).



Fig. 4

3. Check the parts of the parts bag according to the parts bag list (**See Fig. 5**).



Fig. 5

B. Install hydraulic power unit (See Fig. 6)




Fig. 6

C. Install fitting to power unit, and then connecting oil hose (See Fig.7).




Fig. 7


D. Install electrical system

Connect the power source on the data plate of power unit.

Note: For the safety of operators, the power wiring must contact the earth well.

Single phase motor

1. Circuit diagram (See Fig. 8)



2. Connection step (See Fig. 9)

Connecting the two power supply wires to terminals of AC contactor marked L1, L3 respectively.

Earth wire(yellow and green wire) is connected with the earth wire terminal of the motor




Fig. 9

IV. EXPLODED VIEW

MODEL LR06




Fig. 10

Rollers




Fig. 11

PARTS LIST FOR MODEL LR06

Item	Part#	Description	QTY.	Note
1	11630001	Platform	1	
2	10206019	Snap ring $\phi 19$	20	
3	11630003	Pin for drive-thru ramp $\phi 19 \times 452$	2	
4	11630004	Drive-thru ramp	2	
4A	10209010	Snap Ring $\phi 10$	8	
4B	11620043	Pin for roller of drive-in ramp	4	
4C	10620063	Roller of drive-pin ramp (black nylon)	4	
5	11630005	Connecting pin for cylinder $\phi 25 \times 210$	1	
6	10630006	Cylinder	1	
7	11630007	Cylinder base connecting pin $\phi 25 \times 132$	1	
8	10206032	Snap ring $\phi 25$	4	
9	11630008	Frame support connecting pin (Upper) $\phi 19 \times 356$	4	
10	11630009	Frame support (Front)	2	
11	11630010	Frame support connecting pin (Lower) $\phi 19 \times 405$	4	
12	11630011	Frame support (Rear)	2	
13	10630100	Socket bolt M10*40	1	
14	11630013	Safety block	1	
15	11630014	Safety bar set	1	
16	10420020	Hex bolt M10*110	2	
17	10630015	Spring $\phi 15 \times \phi 12 \times 55$	2	
18	10209022	Washer $\phi 10$	2	
19	10209056	Self Locking Nut M10	3	
20	11640024	Rollers	2	
21	10630102	Rubber block 438*1350*5	2	
22	10620034	Rubber pad 120*100*38	4	
23	11630012	Base frame	1	
24	071103	Manual power unit	1	
25	10209003	Hex bolt M8*25	4	
26	10209005	Self Locking Nut M8	4	
27	11640021	Power unit stand	1	
28	10206006	Washer $\phi 12$	2	
29	10420046	Split pin $\phi 3 \times 20$	2	
30	10209064	Straight Fitting	1	
31	10630101	Oil hose 1/4*3650	1	
32	10209060	90° Fitting for power unit	1	
33	10630500	Parts Box	1	

PARTS FOR ROLLER

20-1	11630031	Rollers handle	2	
20-2	10630032	Snap Ring $\phi 12$	8	
20-3	11630033	Connecting Shaft $\phi 12 \times 80$	2	
20-4	11630034	Roller Shaft $\phi 12 \times 65$	2	
20-5	1003275021	White wheel	4	

Cylinder




Fig. 12

Item	Part No.	Description	QTY.	Note
6-1	11630029	Bore Weldment	1	
6-2	11630026	Piston Rod	1	
6-3	10201034	Bleeding Plug	1	
6-4	11630030	Head cap	1	
6-5	10209078	Dust ring	1	
6-6	10620058	O-Ring inside head cap	1	
6-7	10620049	O-Ring outside head cap	1	
6-8	11630028	Piston	1	
6-9	10206069	Small O-Ring for piston	1	
6-10	10630027	O-Ring outside piston	1	
6-11	10620054	Y-Ring OSI	1	
6-12	10620055	Support Ring	1	
6-13	10206071	Nut	1	
6-14	10620064	Greasing Fitting	2	

Manual Power Unit (071103)




Fig. 13

Manual Power Unit 110V/60HZ Single Phase

Item	Part No.	Description	QTY.	Note
1	81400180	Rubber pad	2	
2	81400250	Start capacitor	1	
3	81400200	Run capacitor	1	
4	10420148	Cap head bolt with washer	4	
5	81400066	Cover for capacitor	2	
6	81400363	Motor connecting shaft	1	
7	80101013	Manifold block	1	
8	10209149	Lock washer	4	
9	81400276	Iron plug	1	
10	81400259	Red rubber plug	1	
11	85090142	Socket bolt	4	
12	81400312	Gear pump	1	
13	10209034	Washer	2	
14	81400295	Socket bolt	2	
15	81400365	O-ring	1	
16	10209152	Belt	1	
17	85090167	Magnet	1	
18	81400290	Filter mesh	1	
19	81400412	Motor	1	
20	10420070	Button switch	1	
21	81400559	AC contactor	1	
22	81400287	Cover of motor terminal box	1	
23	71111211	AMGO label	1	
24	81400560	Throttle valve	1	
25	81400266	Release valve	1	
26	81400284	Iron plug	1	
27	10720118	Elastic pin	1	
28	81400451	Handle for release valve	1	
29	10209020	Plastic ball for arm lock	1	
30	81400421	Release valve nut	1	
31	81400422	Release valve shim	1	
32	81400449	Valve seat(Low)	1	
33	81400567	Release valve	1	
34	81400566	Check valve	1	
35	81400375	Oil suction pipe	1	
36	81400376	Oil return pipe	1	
37	81400364	Hose clamp (stainless steel)	1	
38	81400263	Oil tank cap	1	
39	81400320	Oil tank	1	

Illustration of hydraulic valve for power unit




Fig. 14

V. OPERATION INSTRUCTIONS

1. Install the oil hose between oil cylinder and power unit, connect well the power supply wire. The machine can be ready to use.
2. The roller must be disengage when lifting vehicle (**See Fig.17**). To raise and lock the lift: Press the button up till the lift is raised to the required height and the locks are in engaged (**See Fig.15**), then push release handle of the power unit, the lift would be locked.
3. To lower lift: Press the button UP, until the safety lock is in the released position (**See Fig.16**), lower lift by pushing lowering handle.




Fig.15




Fig.16

4. Move lift: Pull up roller bracket, lock two roller to the lift with roller shaft. (**See Fig. 16& 17**). Moving the lift by the power unit stand.




Fig. 17




Fig. 18

1. There are four fixed holes in the machine, can fix the machine on ground by 3/4 X 5 1/2" anchor bolts (**See Fig.19**).




Fig.19

VI. MAINTENANCE SCHEDULE

Monthly:

1. Lubricate all moving parts with lubricant.
2. Check all connectors, bolts and pins to insure proper mounting.
3. Make a visual inspection of all hydraulic hoses/lines for possible wear or leakage.

Every six months:

1. Make a visual inspection of all moving parts for possible wear, interference or damage.
2. Check all fastener and re-torque.

Oil cylinder maintenance:

In order to extend the service life of the oil cylinder, please operate according to the following requirements.

1. Recommend to use N46 anti-wear hydraulic oil.
2. The hydraulic oil of the lifts should be replaced regularly during using. Replace the hydraulic oil 3 months after the first installation, Replace the hydraulic oil once a year afterwards.

3. Make at least one full trip raising and lowering per day. For exhausting the air from the system, which could effectively avoid the corrosion of the cylinder and damage to the seals caused by presence of air or water in the system.
4. Protect the outer surface of the oil cylinder's piston rod from bumping and scratching, and timely clean up the debris on the oil cylinder dust-ring and the piston rod.

VII. TROUBLE SHOOTING

TROUBLE	CAUSE	REMEDY
Motor does not run	<ol style="list-style-type: none"> 1. Start Button does not work 2. Wiring connections are not in good condition 3. Motor burned out 4. AC contactor burned out 	<ol style="list-style-type: none"> 1. Replace start button 2. Repair all wiring connections 3. Repair or replace motor 4. Replace AC Contactor
Motor runs but the lift is not raised	<ol style="list-style-type: none"> 1. Motor runs in reverse rotation 2. Gear Pump out of operation 3. Release Valve in damage 4. Relief Valve or Check Valve in damage 5. Low oil level 6. Overload or system low pressure 	<ol style="list-style-type: none"> 1. Reverse two power wire 2. Repair or replace 3. Repair or replace 4. Repair or replace 5. Fill tank 6. Check load or adjusting the pressure of hydraulic system
Lift does not stay up	<ol style="list-style-type: none"> 1. Release Valve out of work 2. Relief Valve or Check Valve leakage 3. Cylinder or Fittings leaks 	Repair or replace
Lift raises slowly	<ol style="list-style-type: none"> 1. Oil line is jammed 2. Motor running on low voltage 3. Oil mixed with air 4. Gear Pump leaks 5. Overload lifting 	<ol style="list-style-type: none"> 1. Clean the oil line 2. Check electrical system 3. Fill tank 4. Repair or replace pump 5. Check load
Lift can not lower	<ol style="list-style-type: none"> 1. Safety device are in activated 2. Release valve in damage 3. Oil system is jammed 	<ol style="list-style-type: none"> 1. Release the safeties 2. Repair or replace 3. Replace Clean the oil system

VIII. Lift disposal.

When the car lift cannot meet the requirements for normal use and needs to be disposed, it should follow local laws and regulations.



AMGO HYDRAULIC CORPORATION

1931 Joe Rogers Blvd, Manning, South Carolina,

Zip: 29102

Tel: (803) 505-6410

Fax: (803) 505-6410

Manual Part No. : 722215602

Revision Date: : 2022/05