


AMGO  [®] **Hydraulics**

Installation And Service Manual

Original



Motorcycle lift

MC-1200

CONTENTS

| | |
|--|-----------|
| I. Product Features and Specifications..... | 1 |
| II. Installation requirement..... | 2 |
| III. Steps of Installation..... | 3 |
| IV. Exploded View..... | 8 |
| V. Test Run..... | 14 |
| VI. Operation Instruction..... | 16 |
| VII. Maintenance..... | 17 |
| VIII. Trouble shooting..... | 18 |
| IX. Lift Disposal..... | 18 |

I .PRODUCT FEATURES AND SPECIFICATIONS

Motorcycle lift MC-1200:

- Hydraulic direct-drive cylinders, designed and made on high standard, utilizing oil seal in cylinder
- Self-lubricating UHMW Polyethylene sliders and bronze bush
- Non-skid diamond platforms
- Automatic safety release system
- Optional: Width extension kit and length extension kit




Fig.1

MODEL MC-1200 SPECIFICATION

| Model | Capacity | Lifting Height | Lifting Time | Overall Length | Overall Width | Minimum Height | Motor |
|---------|----------|----------------|--------------|----------------|---------------|----------------|-------|
| MC-1200 | 1200LBS | 43" | 23s | 106-1/4" | 29-1/2" | 6" | 1.0HP |

II . INSTALLATION REQUIREMENT

A. TOOLS REQUIRED

✓Rotary Hammer Drill (Φ19)



✓Screw



✓English Spanner (12")



✓Wrench Set: (13#, 15#, 17#, 19#)



✓Ratchet Spanner with Socket: (28#)



✓Grease gun



✓Hook Spanner (40~42mm)



✓Pliers



Fig.2

B. SPECIFICATIONS OF CONCRETE

Specifications of concrete must be adhere to the specifications as following. Failure to do so may result in lift and/or vehicle falling.

1. Concrete must be thickness 100mm minimum and without reinforcing steel bars, and must be dried completely before lift installation.
2. Concrete must be of test strength 210kg/cm² minimum.

C. POWER SUPPLY

The power capacity must be more than 0.75, the power cable size must be no less than 0.003875sq.in and in good condition of connecting to the floor.

III.STEPS OF INSTALLATION

A. Check the parts before assembly to make sure all the parts are completed.

1. Packaged cargo (lift, drive-in ramp, parts box, power unit stand, wheel vise). Move the parts aside, open the outer packing and check the parts according to the shipment parts list. **(See Fig.3)**




Fig.3

2. Open the parts box, check the parts according to the parts list (See Fig. 4).




Fig.4

3. Open the parts bag, check the parts according to the parts list (See Fig. 5).



Fig.5

B. Put the lift and control cabinet in good order and connect the oil hose, see Fig.6




Fig.6

2.1 Step of power unit stand installation




Fig.7

C. Install Electrical System

1. Connect the wire according to below diagram. (Fig.8)




Fig.8

D. Tighten all the oil hose fittings, fill the power unit with right amount hydraulic oil (In order to ensure the service life of the hydraulic system and keep the lift in best performance, please fill No.46 high-quality anti-wear hydraulic oil.)

E. Install adjustable wheel vise and tool tray. (See Fig 9)

1. After connected the circuit wire, lifting the motorcycle lift to a suitable height, install the wheel vise and tool tray as to below photos;
2. The wheel vise can be chosen to install in different installed position of the platform.





Fig.9

F. Install optional width extension kit(MC001). See Fig 10




Fig.10

G. Install optional Length extension kit(MC002). See Fig 11

Note: Connect the holes on platform extension kit and the platform. Install the adjustable fixing device on the platform extension kit.




Fig.11

IV. EXPLODED VIEW

MODEL: MC-1200




Fig.12

Parts list of Lift

| Item | Part# | Description | QTY. | Note |
|------|-------------|---|------|------|
| 1 | 11720020 | Platform | 1 | |
| 2 | 11720723 | Cover plate of Platform | 1 | |
| 3 | 10217069 | Hex bolt M12*30 | 2 | |
| 4 | 11720022 | Drive-in ramp | 1 | |
| 5 | 11720023 | Outer scissor | 1 | |
| 6 | 11720024 | Inner scissor | 1 | |
| 7 | 10610023 | Slider 55*55*39 | 4 | |
| 8 | 11720122 | Pin for safety device | 1 | |
| 9 | 10206019 | Snap ring ϕ 19 | 2 | |
| 10 | 10640050 | Socket bolt M6*10 | 2 | |
| 11 | 11720026-01 | Safety device | 1 | |
| 12 | 11720027-02 | Base | 1 | |
| 13 | 1003085004 | Self-locking nut M18 | 2 | |
| 14 | 10209057A | Bronze bush ϕ 25.4* ϕ 19.2*14.5 | 4 | |
| 15 | 11720007 | Pin for Scissor | 2 | |
| 15A | 10510053 | Washers ϕ 24* ϕ 19.5*1.8 | 6 | |
| 16 | 10720003 | Spring ϕ 2*75 | 5 | |
| 17 | 11720012 | Pin for Spring ϕ 25*82 | 4 | |
| 18 | 10209025 | Hair Pin ϕ 4*25 | 6 | |
| 19 | 11640006A | Cylinder Base Pin ϕ 25*112 | 1 | |
| 20 | 10640007 | Cylinder ϕ 63*290 | 1 | |
| 21 | 11640057 | Pin for Cylinder Connecting ϕ 25*88 | 1 | |
| 22 | 10206032 | Snap ring ϕ 25 | 12 | |
| 23 | 11720009 | Connecting pin ϕ 25*52 | 4 | |
| 24 | 10620136 | Rubber tube ϕ 10*45 (red) | 1 | |
| 25 | 11720111 | Safety Device connecting bar | 1 | |
| 26 | 11720110 | Connecting sleeve | 1 | |
| 27 | 10420018 | Self Locking Nut M6 | 1 | |
| 28 | 10720102 | Socket Bolt M6*18 | 1 | |
| 29 | 10209021 | Hex Nut M10 | 4 | |
| 30 | 10209022 | Washer ϕ 10 | 4 | |
| 31 | 10209039 | Lock Washer ϕ 10 | 4 | |
| 32 | 10720002 | Socket Bolt M10*25 | 4 | |
| 33 | 1103083015 | Wheel vise fixing seat | 1 | |
| 34 | 1103083011 | Support plate (Left) | 1 | |
| 35 | 1103083022 | Positioning adjustment screw rod | 1 | |
| 35A | 1103083019 | Positioning plate | 1 | |
| 35B | 1003083002 | Rubber pad 90*90*5 | 1 | |
| 35C | 10630032 | Snap ring ϕ 12 | 1 | |
| 36 | 10206023 | Self Locking Nut M12 | 3 | |

| Item | Part# | Description | QTY. | Note |
|--|-------------|--|------|------|
| 37 | 10206006 | Washer φ12 | 6 | |
| 38 | 1103083010 | Support plate (Right) | 1 | |
| 39 | 1103083016 | Wheel vise moving board | 1 | |
| 40 | 1103083012 | Adjusting Pin | 1 | |
| 40A | 1103083009W | Guide Pillar | 2 | |
| 40B | 10209066 | Hex Nut M16 | 2 | |
| 41 | 1103083007 | Handle Connecting plate | 1 | |
| 42 | 1103083017 | Control Handle | 1 | |
| 43 | 10410040 | Socket Bolt M12*110 | 1 | |
| 44 | 11420245 | Straight fitting J0065 G3/8-19(M)*3/8NPT(F) | 1 | |
| 45 | 11420244 | Straight fitting J0064 1/4NPT-18(M)*G3/8-19(M) | 1 | |
| 46 | 10420119 | Straight fitting 3/8NPT(M)*1/4JIC(M) | 1 | |
| 47 | 10440042 | Oil Hose 1/4*2550mm (straight+90°) | 1 | |
| 48 | 10209060 | 90° Fitting 3/8SAE0/R(M)*1/4JIC(M) | 1 | |
| 49 | 11720131 | Power Unit Stand | 1 | |
| 50 | 10209005 | Self Locking Nut M8 | 4 | |
| 51 | 10209004 | Rubber Ring | 4 | |
| 52 | 10209003 | Hex Bolt M8*25 | 4 | |
| 53 | 10209059 | Anchor Bolt 3/4*5-1/2 | 4 | |
| 54 | 10720013 | Safety Cable L=1120mm | 1 | |
| 55 | 10720014 | Securing belt (Optional) | 1 | |
| 56 | 10720500 | Part Box | 1 | |
| 57 | 11720100 | Tool Tray bracket | 1 | |
| 58 | 10206156 | Tool Tray | 1 | |
| 59 | 071103 | Power unit | 1 | |
| 70 | 86010782 | Wheel vise assy. | 1 | |
| 71 | 11630103 | Straight fitting J0020 1/4NPT(M)*1/4NPT(F) | 1 | |
| 72 | 11720114 | Balance valve(0.7) | 1 | |
| Optional: Width extension kits (MC001) | | | | |
| 60 | 10720036 | Connecting pin | 2 | |
| 61 | 10720035 | Width extension platform | 2 | |
| 62 | 11209012 | Hair pin φ3.2 | 4 | |
| 63 | 10217069 | Hex bolt M12*30 | 4 | |
| 64 | 11720034 | Width extension drive-in ramp | 2 | |
| Optional: Length Extension kits (MC002) | | | | |
| 65 | 10209126 | Hex bolt M10*25 | 4 | |
| 66 | 10209039 | Lock Washer φ10 | 4 | |
| 67 | 10209022 | Washer φ10 | 4 | |
| 68 | 10209021 | Hex nut M10 | 4 | |
| 69 | 11720062 | Extension platform | 1 | |

4.1 Cylinder (10640007)




Fig.13

Parts for cylinder

| Item | Part# | Description | QTY. | Note |
|-------|-----------|-------------------------|------|------|
| 20-1 | 11640030A | Bore Weldment | 1 | |
| 20-2 | 11640031A | Piston Rod | 1 | |
| 20-3 | 10201034 | Bleeding Plug | 1 | |
| 20-4 | 11201033 | Head Cap | 1 | |
| 20-5 | 10209078 | Dust seal | 1 | |
| 20-6 | 10201032 | O Ring inside head cap | 1 | |
| 20-7 | 10201035 | O Ring outside head cap | 1 | |
| 20-8 | 11201028 | Piston | 1 | |
| 20-9 | 10206069 | Small O Ring for piston | 1 | |
| 20-10 | 10201031 | O Ring outside piston | 1 | |
| 20-11 | 10201030 | Y Ring OSI | 1 | |
| 20-12 | 10201029 | Support Ring | 1 | |
| 20-13 | 10206071 | Nut | 1 | |
| 20-14 | 10620064 | Oil nozzle | 2 | |

4.2 Power unit (071103)

Single phase 110V 60Hz Manual power unit




Fig.14

Parts for Manual power unit

| Item | Part# | Description | QTY. | Note |
|------|----------|------------------------------|------|------|
| 1 | 81400180 | Rubber pad | 2 | |
| 2 | 81400250 | Start capacitor | 1 | |
| 3 | 81400200 | Run capacitor | 1 | |
| 4 | 10420148 | Cap head bolt with washer | 4 | |
| 5 | 81400066 | Cover for capacitor | 2 | |
| 6 | 81400363 | Motor connecting shaft | 1 | |
| 7 | 80101013 | Manifold block | 1 | |
| 8 | 10209149 | Lock washer | 4 | |
| 9 | 81400276 | Iron plug | 1 | |
| 10 | 81400259 | Red rubber plug | 1 | |
| 11 | 85090142 | Socket bolt | 4 | |
| 12 | 81400312 | Gear pump | 1 | |
| 13 | 10209034 | Washer | 2 | |
| 14 | 81400295 | Socket bolt | 2 | |
| 15 | 81400365 | O-ring | 1 | |
| 16 | 10209152 | Belt | 1 | |
| 17 | 85090167 | Magnet | 1 | |
| 18 | 81400290 | Filter mesh | 1 | |
| 19 | 81400412 | Motor | 1 | |
| 20 | 10420070 | Button switch | 1 | |
| 21 | 81400559 | AC contactor | 1 | |
| 22 | 81400287 | Cover of motor terminal box | 1 | |
| 23 | 71111211 | AMGO label | 1 | |
| 24 | 81400560 | Throttle valve | 1 | |
| 25 | 81400266 | Release valve | 1 | |
| 26 | 81400284 | Iron plug | 1 | |
| 27 | 10720118 | Elastic pin | 1 | |
| 28 | 81400451 | Handle for release valve | 1 | |
| 29 | 10209020 | Plastic ball for arm lock | 1 | |
| 30 | 81400421 | Release valve nut | 1 | |
| 31 | 81400422 | Release valve shim | 1 | |
| 32 | 81400449 | Valve seat(Low) | 1 | |
| 33 | 81400567 | Release valve | 1 | |
| 34 | 81400566 | Check valve | 1 | |
| 35 | 81400375 | Oil suction pipe | 1 | |
| 36 | 81400376 | Oil return pipe | 1 | |
| 37 | 81400364 | Hose clamp (stainless steel) | 1 | |
| 38 | 81400263 | Oil tank cap | 1 | |
| 39 | 81400320 | Oil tank | 1 | |

Illustration of hydraulic valve for power unit




Fig.15

V. TEST RUN

1. Install anchor bolts. see Fig.16

Install the anchor bolts to fix the machine after installing.




Fig.16

Steps:

Note: Twisting force is 150N.m for fixing the anchor bolt, knock the anchor bolt into the ground at least 2-3/4".




Fig.17

2. Adjust safety cable

Rise the lift to the highest position (**See Fig.18**), rotating the safety lock handle as the direction of arrow. Loosen the screw of the safety cable by spanner, lift up the safety lock plate from the rack about 1/2"~3/4" (**See Fig.19**), then tighten the safety cable by spanner.




Fig.18




Fig.19

VI. OPERATION INSTRUCTIONS

1. Install well the oil hose between cylinder and power unit, connected the wire, the motorcycle lift can be operated.

2. Rise up the lift without motorcycle for testing.

3. To lift motorcycle

Lower the lift to the lowest position, loosen the wheel vise. Move the motorcycle to the platform, put the front wheel into the wheel vise, set well the motorcycle. Put up the foot stool of the motorcycle. Rotated handle to clamp the wheel. Tighten the securing belt. Make sure the wheel is tightened and the securing belt is fixed before using. **(See Fig.20)**






Fig.20

4. To lower the lift: Rise the lift for several seconds. Rotate the safety lock handle downward **(see Fig.21)** to release the safety device. After the safety device is released **(see Fig.22)**, press the release handle in the power unit, the lift would be lowered.



Safety device is locked
Fig.21



Safety device is released
Fig.22

VII. MAINTENANCE SCHEDULE

Monthly maintenance:

1. Lubricate all moving parts with lubricant.




Fig.23

2. Check all connectors, bolts and pins to insure proper mounting.
3. Make a visual inspection of all hydraulic hoses/lines for possible wear or leakage

Every six months:

1. Make a visual inspection of all moving parts for possible wear, interference or damage.
2. Check all fasteners and re-torque

Oil cylinder maintenance:

In order to extend the service life of the oil cylinder, please operate according to the following requirements.

1. Recommend to use N46 anti-wear hydraulic oil.
2. The hydraulic oil of the lifts should be replaced regularly during using. Replace the hydraulic oil 3 months after the first installation, Replace the hydraulic oil once a year afterwards.
3. Make at least one full trip raising and lowering per day. For exhausting the air from the system, which could effectively avoid the corrosion of the cylinder and damage to the seals caused by presence of air or water in the system.
4. Protect the outer surface of the oil cylinder's piston rod from bumping and scratching, and timely clean up the debris on the oil cylinder dust-ring and the piston rod.

VIII.TROUBLE SHOOTING

| NO | TROUBLE | CAUSE | REMEDY |
|----|---------------------------------------|---|---|
| 1 | Motor does not run | <ol style="list-style-type: none"> 1. Button does not work 2. Wiring connections are not in good condition 3. Motor burned out 4. AC contactor burned out | <ol style="list-style-type: none"> 1. Replace button 2. Repair all wiring connections 3. Repair or replace motor 4. Replace AC Contactor |
| 2 | Motor runs but the lift is not raised | <ol style="list-style-type: none"> 1. Motor runs in reverse rotation 2. Release Valve in damage 3. Gear Pump out of operation 4. Relief Valve or Check Valve in damage 5. Low oil level 6. Overload lifting or low pressure | <ol style="list-style-type: none"> 1.Reverse two power wire 2. Repair or replace 3. Repair or replace 4. Repair or replace 5. Fill tank 6.Check load or adjust the pressure |
| 3 | Lift does not stay up | <ol style="list-style-type: none"> 1. Release Valve out of work 2. Relief Valve or Check Valve leakage 3. Cylinder or Fittings leaks | <p>Repair or replace</p> <p>Repair or replace</p> <p>Replace fitting and oil seal</p> |
| 4 | Lift rises slowly | <ol style="list-style-type: none"> 1. Oil line is jammed 2.Motor running on low voltage 3. Oil mixed with air 4. Gear Pump leaks 5. Overload lifting | <ol style="list-style-type: none"> 1. Clean the oil line 2. Check Electrical System 3. Fill tank 4. Repair or replace 5. Check load |
| 5 | Lift cannot lower | <ol style="list-style-type: none"> 1. Safety device are not in activated 2. Release Valve in damage 3. Oil system is jammed | <ol style="list-style-type: none"> 1. Release the safety device 2. Repair or replace 3. Clean the oil system |

IX. Lift disposal.

When the car lift cannot meet the requirements for normal use and needs to be disposed, it should follow local laws and regulations.



AMGO HYDRAULIC CORPORATION

1931 Joe Rogers Blvd, Manning, South Carolina, USA

Zip: 29102

Tel: (803) 505-6410

Fax: (803) 505-6410

Manual no: 72267605

Revised date: 2022/03