



Original

# Installation And Service Manual

## FOUR POST LIFT

### Model:PRO-12, PRO-12A, PRO-12AX

#### Cargo Claims

If there is any missing or damaged product during transportation, the buyer must notate on the shipping paperwork or refuse the shipment.  
NOTATE ALL DAMAGE OR REFUSE  
DAMAGED SHIPMENT!

#### ⚠ DANGER

Read the entire contents of this manual before using this product. Failure to follow instructions and safety precautions could result in serious injury or even death. Make sure all other operators also read this manual. Keep this manual near the machine so that it can be seen by all users. By proceeding with installation and operation, you agree that you are fully understand the contents of this manual and take full responsibility for the use of the product.

# CONTENTS

Profile .....	1
Important Safety Instructions.....	3
I.Product Features And Specifications .....	5
II.Installation Requirement .....	6
III.Installation Steps.....	8
IV.Exploded View .....	29
V.Test Run .....	37
VI.Operation Instructions.....	38
VII.Maintenance Schedule .....	38
VIII.Trouble Shooting .....	40
IX.Car Lift Safety Tips.....	41
X.Lift Disposal.....	41

## **Explanation of the safety warning symbols used in this manual**

 DANGER	Risk of death or injury
 WARNING	Dangerous or unsafe practices that may result in death or injury
 CAUTION	Dangerous or unsafe practices that may result in personal injury, product damage or property damage
ATTENTION	Conditions that may result in damage to products or property

## PROFILE

The four post lift is a commonly used vehicle repair and maintenance tool that uses a hydraulic or electric system that can lift the car up to a certain height so that the vehicle can be placed in a suitable position for inspection and repair. Car lifts can be divided into pneumatic and electric, which have the characteristics of safe and reliable, simple structure and quick installation. This instruction manual is specially prepared for you. Your new lift is the product of over a decade of continuous research, testing and development and is the most technologically advanced lift on the market today.

**Please make sure to read through this manual before operating the lift.**

Record the information on the nameplate label here:

Model No.:\_\_\_\_\_

Serial No.:\_\_\_\_\_

Manufacturer date:\_\_\_\_\_

## WARRANTY

The warranty period for the steel structure part of new car lift is 5 years; hydraulic components, bronze bushings, slider blocks and plastic parts are warranty for 3 years; electrical components and cables are warranty for 2 years. Rubber pads are without warranty. During the warranty period, the manufacturer will repair or replace the defective parts free of charge including shipping costs.

This warranty does not cover damage caused by normal wear and tear, improper use, damage in transit, or damage caused by lack of maintenance.

This warranty is unique and supersedes what is expressed and implied in all other warranties. The manufacturer shall not be liable for any particular, indirect or accidental damage resulting in breach of or delay in the execution of the warranty. The manufacturer reserves the right to design and improve the product and has no obligation to make notice of the changes in advance. The product warranty based on the above clause is based on the model number and serial number of the equipment. This information must be provided in conjunction with all warranty information at the time of service and warranty.

## SAFETY WARNING LABEL



## **IMPORTANT SAFETY INSTRUCTIONS**

In order to properly maintain your product and ensure operator safety, it is the responsibility of the product owner to read and follow these instructions!


1. Ensure product installation full complies with all applicable local and national rules, ordinances and regulations;
2. Ensure that all operators are properly trained, know how to operate the unit safely, and are properly supervised;
3. Do not operate the lift until you are sure all parts are in place and operating correctly;
4. Keep your hands and feet away from the machine. Keep hands and feet away from any moving parts. Keep your feet away from the lift as it descends and avoid pressing on pointed objects;
5. Keep the work area clean. A cluttered workspace can lead to injuries;
6. The machine is only approved for indoor installation and use. Outdoor installation is prohibited;
7. Only trained operators are allowed to handle the lift machine. All untrained persons must stay away from the workplace. Never allow untrained persons to handle or operate the machine;
8. Use the lift properly. Use the lift in the correct way;
9. Warning! Keep persons and objects from the lift when lifting the a vehicle;
10. If the vehicle is at risk of falling, make sure no one is around the lift;
11. Before preparing to approach or service the vehicle, ensure that the safety device is in effect;
12. Dress appropriately when operating machines, and consider wearing non-slip steel-toe shoes for safety;
13. Beware of electric shock. In order to protect the operator from electric shock, the lift in use must be grounded. Do not connect the green wire to the terminal. This is the ground wire;
14. Danger! The power supply used in this type of lift has high voltage. Please disconnect the power supply before any circuit repair. Unplug in case the power supply is accidentally switched on during maintenance;
15. Warning! There is a risk of explosion. There are parts in the equipment that produce arc light and spark. Do not operate near flammable gas. This machine should not be placed in the lounge or basement;
16. Maintain with care. Keep the machine clean for better and safer operation. Perform proper lubrication and maintenance procedures according to the manual. Keep handles or buttons clean, dry, and free of oil;
17. Stay alert. Use common sense to observe what you are doing and stay alert;

18. Check for damaged parts. Check for adjustments to moving parts, damage to parts, or anything that may affect their operation. Do not use the machine if the parts are damaged;
19. Do not remove relevant safety parts from the machine. Do not use a lift if it is damaged or missing;
20. Operate the lift only at temperature between 5°C to 40°C (41°F to 104°F).


 **DANGER** Be very careful when installing, operating, maintaining or repairing this equipment. Failure to comply may result in property damage, product damage, injury or (in very rare cases) death. Ensure that only authorized personnel operate the equipment. All repairs must be carried out by an authorized technician. Do not modify the machine, this voids the warranty and increases the probability of personal injury or property damage. Ensure to read and follow this instructions on the label.

## I. PRODUCT FEATURES AND SPECIFICATIONS FEATURES

- Manual control air-operated system.
- Mechanical self-lock and air-driven safety release.
- Manual hydraulic power system, cable-driven.
- Strengthen and Non-skid diamond platforms.
- Adjustable platform and adjustable safety lock ladders.
- Optional Jack: With hand pump or pneumatic pump.
- Optional Turnplates: Alignment model only



**PRO-12**  
**Fig.1**



**PRO-12A,PRO-12AX**  
**Fig.2**

### SPECIFICATIONS

Model	Lifting Capacity	Lifting Time	Overall Length (Incl. Ramps)	Overall Width	Width between columns	Max. Lifting Height	Max. Locking height	Overall Height	Minimum Height
PRO-12	12,000lbs	63S	239 13/16"	126 5/16"	112 1/4"	74 7/16"	71 1/4"	86"	6 11/16"
PRO-12A	12,000lbs	63S	239 13/16"	126 5/16"	112 1/4"	76 3/8"	73 1/4"	86"	8 11/16"
PRO-12AX	12,000lbs	63S	239 13/16"	132 1/8"	118 1/8"	76 3/8"	73 1/4"	86"	8 11/16"

Model	Max. height underneath runways	Max. Locking height underneath runways	Drive-Thru Clearance	Width between runways		Outside edge of runways		Motor
				Standard Width	Adjustable width range	Standard Width	Adjustable width range	
PRO-12	68 7/8"	65 3/4"	98 3/8"	43 5/16"	38"~50 7/8"	83 5/16"	78"~90 7/8"	2.0HP
PRO-12A	68 7/8"	65 3/4"	98 3/8"	43 5/16"	38"~50 7/8"	83 5/16"	78"~90 7/8"	2.0HP
PRO-12AX	68 7/8"	65 3/4"	104 3/16"	43 5/16"	38"~53 3/4"	83 5/16"	78"~93 3/4"	2.0HP

**CAUTION** When driving the vehicle into the lift, make sure it is positioned in middle of either group of runways. Any hit of the lift could result in damage to either the vehicle or lift.

## II. INSTALLATION REQUIREMENT

### A. TOOLS REQUIRED

☛ Rotary Hammer Drill ( $\Phi 19$ )



☛ Hammer



☛ Level Bar



☛ English Spanner (12")



☛ Wrench Set  
(10#, 12#, 13#, 14#, 17#, 19#, 24#, 30#)



☛ Ratchet Spanner with Socket (28#)



☛ Carpenter's Chalk



☛ Screw Sets



☛ Tape Measure (7.5m)



☛ Pliers



☛ Lock Wrench



☛ Socket Head Wrench  
(3#, 5#, 6#)



Fig. 3

## **B. Equipment storage and installation requirements:**

- 1 . Store the equipment in a dry, non-moldy, non-flammable environment.
- 2 . The lift is generally approved for indoor installation and use. If need outdoor installation, the optional motor protect cover is required.
- 3 . When installing the device, take safety precautions according to the instructions to avoid device damage.
- 4 . During installation, all parts should be fastened to ensure the stability and smooth operation of the machine.
5. After installation, the whole machine should be checked to make sure that every component is working properly.

## **C. The equipment should be unload and transfer by forklift.**




**Fig. 4**

## **D. SPECIFICATIONS OF CONCRETE (See Fig. 5)**

**Specifications of concrete must be adhered to the specification as following.**

**Failure to do so may result in lift and/or vehicle falling.**

1. Concrete must be thickness 4" minimum and without reinforcing steel bars, and must be dried completely before the installation.
2. Concrete must be in good condition and must be of test strength 3,000 psi (210kg/cm<sup>2</sup>) minimum. Solidify at least 15 days.
3. Floors must be level and no cracks.



**Fig. 5**

## E. AIR SUPPLY

Air pressure requirement: 0.5-0.8Mpa, Air line size  $\phi 8 \times \phi 6$  and  $\phi 6 \times \phi 4$ .

## F. POWER SUPPLY

1. You are required to use a licensed and qualified electrician for the installation process.
2. The power supply capacity must be more than 3.0HP, with a cord larger than 12AWG, and must be properly grounded.

**DANGER** All electrical wiring must be performed by a licensed and certified electrician. Attempting to connect the circuit without proper certification may result in damage to the lift or electrocution, resulting in serious injury or death.

## III. INSTALLATION STEPS

### A. Location of installation

Check and insure the installation location (concrete, layout, space size etc.) is suitable for lift installation.

### B. Check the parts before assembly

1. Packaged lift and hydraulic power unit (**See Fig. 6**).



Fig. 6

2. Remove the package and check the parts according the shipment list. (**See Fig. 7**).




Fig. 7

Shipment Parts List


3. Move the columns and drive-in ramps aside to the installation position. (**See Fig. 8**).




Fig. 8

4. Loose the screws of the upper package stand, take off the offside platform, take out the parts inside the power-side platform, then remove the package stand.

5. Move aside the parts and check the parts according to the shipment parts list  
**(See Fig. 9).**



**PRO-12**  
**Fig. 9**



**PRO-12A/PRO-12AX**  
**Fig. 10**

6. Check the parts of parts box according to the parts box lift .  
(See Fig. 11).



Fig. 11

7. Check the parts of the parts bag according to the parts bag list (See Fig. 12).





Fig. 12



**C. Use a carpenter's chalk line to establish installation layout make sure the size is right and base is flat (see Fig. 13). Note: Reserve space before and behind the installation site.**



**Fig. 13**

Model	A	B	C
PRO-12	203-15/16"	126-1/4"	239-7/8"
PRO-12A	203-15/16"	126-1/4"	239-7/8"
PRO-12AX	203-15/16"	132-1/8"	243"

**D. Install cross beams (See Fig. 14, Fig. 15).**



## E. Fix the anchor bolts

1. Prepare the anchor bolts (See Fig. 16).




Fig. 16

2. Using the prescribed rotary hammer drill, and drill all the anchor holes and install the anchor bolts, do not tighten the anchor bolts first (See Fig. 17).

**Note: Minimum embedment of anchors is 3-1/2".**




Fig. 17

## F. Install the safety ladders

1. Take off the pulley safety cover and unscrew the four upper nuts of the Safety Ladders, and then adjust the four lower nuts to be at the same position. Withdraw the Slack-cable safety lock of the Cross-beam to insert the Safety Ladder in, raise the Safety Ladder, and screw the upper nuts (See Fig. 18.)




Fig. 18

2. Install safety ladders (See Fig. 19).




Fig. 19

G. Put the Cross Beams at the same height (See Fig. 20)





Fig. 20

## H. Install power-side platform.


1. Put the power-side platform upon the cross beams by forklift or manual, offset the cross beams to the outside till the pulleys of both platforms can set up into the cross beam (**See Fig.21,22**), Install the power-side platform and screw up the bolts (**See Fig.23**).



**Fig.23**


## I. Install platforms.

1. In the same way, place the off side platform on cross beams, align the holes and tighten with bolts (See Fig. 24).



**Fig. 24**



Note: The standard dimension between platforms is 43 3/8". Once it's not suitable for some special vehicles, you can install the lock plates under the two ends of the off side platform, (see fig 25) and remove the bolts that used to fix the platform and cross beams, then the off side platform can be moved to adjust the dimension between platforms.



**Fig. 25**


## Dimension adjustment range

Model	Dimension	Min. Dimension	Max. Dimension
PRO-12		38"	50 7/8"
PRO-12A		38"	50 7/8"
PRO-12AX		38"	53 3/4"



**J. Assembly offside platform and slider block, (See Fig. 28) check the plumbness of columns with level, adjusting with the shims if not, and then tighten the anchor bolts (See Fig. 29).**

Check the plumbness of columns with level bar, adjust with the shims if necessary.



**Install the slider block**

**C View**  
**Fig. 28**

Use the ratchet spanner with socket to tighten the bolts

Note: Torque of Anchors is  
150N.m(1328lbf.n)

**Fig. 29**

## K. Install cables

1. Pass through the cables from the platform to the columns according to the number of the cables (See Fig. 30).




Fig. 30


No. Cable	①	②	③	④	Model
Length (w/ fitting)	151-3/4"	412-3/8"	214-15/16"	349-3/16"	PRO-12 PRO-12A
	154-3/4"	415-3/4"	217-15/16"	352-3/16"	PRO-12AX

2. The cable pass through the cross beam to top plate of columns and be screwed with cable nuts (See Fig. 31, 32), then install the cable limit pin. (See Fig. 33)





Pass the cable through between the pulley and tension pulley

**D View**  
**Fig.31**




Pass the cable through top plate and tighten with cable nut.


**E View**  
**Fig.32**



3. Illustration for platform cables (See Fig. 34, 35, 36).



**Fig. 34**




**Fig. 35**



**Fig. 36**


## L. Install oil-water separator, manual control air valve and power unit

(See Fig. 37).



## M. Install hydraulic system.


**Note:** Oil hoses and oil return pipe connected to oil cylinder must be passed above the cable and cylinder inlet port must swing upward to avoid the oil hose and oil return pipe scratched by cable.




## N. Install air-line system

- 1.Cut off the  $\phi 6 * \phi 4$  black air line from the crossbeam between two retainers, and then connect to the T fitting (No.68). (See Fig. 42).
- 2.Fix the T fitting (NO.69) with nut (NO.69A) on the platform and connect to the straight fitting (NO.70) . (See Fig. 43).
- 3.Connect two T fittings which installed in step 1 & step 2 with  $\phi 6 * \phi 4$  black air line as shown. Connect the manual air valve to the straight-fitting(NO.70).

Note: the actual length of air line can be cut by installer.(See Fig. 44, Fig. 45).




4. Connecting Oil-water separator and manual control air valve with  $\varphi 8 * \varphi 6$  air line(No.72)(**See Fig. 45**)



**Fig. 45**

5. Connecting air inlet (Air supply pressure 5-8kg/cm<sup>2</sup>), adjusting the air pressure of Oil-water separator to 0.8 MPa (**See Fig. 46**).



**Fig. 46**


## O. Install Electrical System

Connect the power source on the data plate of Motor.

**Note: For the safety of operators, the power wiring must contact the floor well.**

### Single phase motor (See Fig. 47)

1. When the input power supply is one live line (L) and one neutral line (N), the live line is connected to the L1 terminal of the AC contactor, and the neutral line is connected to the L3 terminal of the AC contactor.
2. When the input power supply is two live wires, the two live wires are respectively connected to the wiring terminals marked L1 and L3 on the AC contactor.
3. Earth wire( yellow and green wire) is connected with the earth wire terminal of the motor.




**Fig. 47**

**⚠ DANGER** All electrical wiring must be performed by a licensed and certified electrician. Before ensuring the main power has disconnected from the lift and cannot be re-applied until all procedures have been completed, do not perform any maintenance or installation to the lift.


**⚠ DANGER** Do not use the lift if the wires are damaged or severely worn. If the vehicle rises without noticing damage or extreme wear, carefully lower the vehicle to the ground. Once the lift is on the ground, remove it, disconnect the power, and arrange for protection.

**P. Install spring and safety cover of cross beam (See Fig. 48).**



**Fig. 48**



**Q. Install drive-in ramp (See Fig. 49)**



**Fig.49**

No	Pin no	Part name	QTY
35-1	11420003	Drive in ramp (PRO-12)	2
	11430002	Drive in ramp (PRO-12A、PRO-12AX)	2
35-2	11610667	Roller	4
35-3	11620043	Roller Pin	4
35-4	10209010	Clip pin φ10	8

**R. Install tire stop plate, turnplate adjusting block, limit rod (See Fig. 50)**



After install the turnplate cover and adjustable blocks, install the limit rod.

**Fig.50**

## IV. EXPLODED VIEW

MODEL: PRO-12





Fig. 51

**Model: PRO-12A PRO-12AX**



**Fig. 52**

**PARTS LIST FOR PRO-12, PRO-12A, PRO-12AX**

<b>Item</b>	<b>Part No,</b>	<b>Description</b>	<b>PRO-12</b>	<b>PRO-12A</b>	<b>PRO-12AX</b>
1	11420011A	Power-side Column	1	1	1
2	1104011001A	Offside Column	3	3	3
3	1104732001C	Cross Beam Assy.	2	2	0
	1104412001C	Cross Beam Assy.	0	0	2
5	10209059	Anchor Bolt 3/4*5-1/2	16	16	16
6	11410022	Safety Ladder	4	4	4
7	10420175A	Hex Nut M20	16	16	16
8	11440038-03	Power-side Platform	1	0	0
	11450002-03		0	1	1
9	1104093003A-01	Pulley Pin	1	1	1
9A	1104093002A-01	Pulley Pin	1	1	1
9B	10620064	Greasing Fitting	2	2	2
10	10476024	Pulley washer	14	14	14
11	11476636	Pulley	6	6	6
11A	1004094002	Bush	6	6	6
11B	10420132A	Bronze Bush for Pulley	4	4	4
12	10209043	Hex Bolt M8*20	10	10	10
12A	1004514007	Hex Bolt M10*20(level 8.8)	2	2	2
12B	10209039	Lock Washer φ10	2	2	2
12C	10209022	Flat Washer φ10	10	10	10
12D	1004014006	Hex Bolt M10*25(level 8.8)	8	8	8
12E	10209021	Hex Nut M10	8	8	8
13	10209034	Lock Washer φ8	2	2	2
13A	10209033	Flat Washer φ8	2	2	2
13B	10217002	Hex Nut M8	2	2	2
14	10209022	Flat Washer φ10	2	2	2
15	10420030	Hex Bolt M16*40	12	12	12
16	10420137	Lock Washer φ16	12	12	12
17	10420029	Flat Washer φ16	12	12	12
18	11440039-03	Offside Platform	1	0	0
	11450001-03		0	1	1
19	10600015	Socket Bolt M10*120	4	4	4
20	10420145	Oil-water Separator	1	1	1
21	1004334013	Quick Fitting (1/4NPT)	1	1	1
22	10209009	Round Head Bolt M6*8	4	4	4
23	10420076	90° Fitting	1	1	1
24	10420159	Straight Fitting for Air Line 6*8	1	1	1
25	11420160	Mounting Plate of Manual Control Valve	1	1	1
26	10420161	Nylok Nut M4	2	2	2
27	10420162	Manual Control Air Valve	1	1	1
28	10420163	Straight Fitting	1	1	1
29	10420148	Flat Washer φ4	4	4	4

<b>Item</b>	<b>Part NO.</b>	<b>Description</b>	<b>PRO-12</b>	<b>PRO-12A</b>	<b>PRO-12AX</b>
30	10420164	Round Head Bolt M4*30	2	2	2
31	071102	Manual Power Unit	1	1	1
32	10209005	Nylok Nut M8	14	14	14
33	10209004	Rubber Ring	4	4	4
34	1061K050	Hex Bolt M8*30	4	4	4
35	1042003	Drive-in Ramp assy.	2	0	0
	86010649		0	2	2
36	10209066	Hex Nut M16	4	4	4
37	11620043	Drive-in Ramp pulley pin	4	4	4
38	10209010	Clip Ring	8	8	8
39	10420156	Protecting Ring	1	1	1
40	10420045	Flat Washer φ6	20	20	20
41	11420004	Pin for Drive-in Ramp	2	2	2
42	10420005	Set screw M5*8	4	4	4
43	10440501	Part Box	1	0	0
	10450501		0	1	1
44	11420031-1	Tire stop plate	2	2	2
45	10201005	Cotter Pin	1	1	1
46	10620065	Shim 1mm	20	20	20
	10201090	Shim 2mm	20	20	20
47	10209056	Nylok Nut M10	4	4	4
48	11420217	Cable limit pin	4	4	4
49	11420007	Lock plate	4	4	4
50	11420012A	Cylinder fixing ring	1	1	1
51	10420012	Cylinder	1	1	1
52	11460078	Cable connecting plate	1	1	1
53	10420014	Hex nut M27	1	1	1
54	10420016B	Bellow pipe	1	1	1
55	10440078-01	①Cable L=151 3/4"	1	1	0
	10450005-01	①Cable L=154 3/4"	0	0	1
56	10440081-01	②Cable L=412 3/8"	1	1	0
	10450008-01	②Cable L=415 3/4"	0	0	1
57	10440079-01	③Cable L=214 15/16"	1	1	0
	10450006-01	③Cable L=217 15/16"	0	0	1
58	10440080-01	④Cable L=349 3/16"	1	1	0
	10450007-01	④Cable L=352 3/16"	0	0	1
59	10420166	90° Fitting	1	1	1
60	11420243	Transition Fitting	1	1	1
61	10440042	Oil Hose (straight+90°)	1	1	1
62	10420120	Extended Straight Fitting (with Nut)	1	1	1
63	10207026	Oil Hose L=59 13/16"	1	1	1
64	10209060	90° Fitting	1	1	1
65	10420095	Straight Fitting	1	1	1

Item	Part No.	Description	PRO-12	PRO-12A	PRO-12AX
66	10420245	Straight Fitting	1	1	1
67	C802004	Flow compensation valve	1	1	1
67A	10201020	90° Fitting	1	1	1
68	10420124	T-Fitting	2	2	2
69	1004014007	T-Fitting	1	1	1
69A	1004014008	Thin nut G1/4	1	1	1
70	10420241	Straight Fitting	1	1	1
71	10420195A	Oil Return Hose L=244 1/16"( black)	1	1	1
	10610114	Oil Return Hose L=248" (black)	0	0	1
71A	10420131B	Air Line L=φ307 7/8"	1	1	1
	10450009	Air Line L=φ311"	0	0	1
72	10420167A	Air Line L=φ18 1/8"	1	1	1
73	11476635	Pulley	4	4	4
75	1040101	Turnplate(Optional)	0	2	2
76	11430004-01	Turnplate cover	0	4	4
77	11520037	Pin	0	4	4
78	11450003	Slip plate	0	2	2
79	10420157	Steel ball set	0	60	60
80	11480033	Turnplate block	0	4	4
81	11480045	Turnplate block	0	4	4
82	10400303001	Turnplate block bar	0	4	4

## CROSS BEAM




Fig. 53

<b>Parts list for Cross Beam</b>			
<b>Item</b>	<b>Part No.</b>	<b>Description</b>	<b>Qty</b>
3-1	11420254B-01	Cross Beam for PRO-12(A)	2
	11480023B	Cross Beam for PRO-12AX	2
3-2	10420051B	Protective cover	4
3-3	10209009	Round Head Bolt M6*8	8
3-4	11420044	Limit Block	4
3-5	10420138	Socket Bolt M6*16	8
3-6	11420038	Pin	12
3-7	10420037	Clip Ring	24
3-8	10480113	Spring	8
3-9	10209021	Hex Nut M10	8
3-10	10420049	Split Pin	4
3-11	10420048	Air Cylinder	4
3-12	10420047	Fitting for Air Cylinder	4
3-13	10420046	Cotter Pin	8
3-14	10420042	Slider block	8
3-15	10209033	Flat Washer φ8	24
3-16	10420043	Socket Bolt M8*20	16
3-17	11420175	Slack-cable safety lock (left & right)	2/2
3-18	11420171	Pin	8
3-19	11420172	Pin Bush	8
3-20	10206019	Clip Ring	16
3-21	10209010	Clip Ring	4
3-22	10420035	Tension Pulley	4
3-23	11420174	Spacer	4
3-24	11420041A	Pulley Pin	4
3-25	11420040A	Pulley Bush	4

## CYLINDERS C804407 (Old code 10420012-01)





Fig. 54

Item	Part No.	Description	Qty
51-1	10420059	Dust Ring	1
51-2	104016001	Y- Ring USH	1
51-3	11420061	Head Cap	1
51-4	10420062	O- Ring	1
51-5	11420063	Bore Weldment	1
51-6	11420064	Piston Rod	1
51-7	11420065	Pin	1
51-8	10420066	Support Ring	1
51-9	10420067-01	Y- Ring USH	1
51-10	11420068	Piston	1


## Illustration of hydraulic valve for power unit



**Fig 55**

## V. TEST RUN

1. Fill the reservoir with approximately 11 L Hydraulic Oil (**Note:** In consideration of Power Unit's durability, please use **Hydraulic Oil 46#**).
2. Press button **UP**, the Cables will be strained. Check whether the Cables match the Pulley. Make sure the Cables are not across.
3. Press the Handle of release valve to lock the Cross-beam to the safety ladders, and then adjust the platforms to be level by adjusting the nuts of Safety Ladders.
4. Adjust the tension of the cables by cable nuts. You need to run the lift up and down for several times till the four safety devices can be locked and released simultaneously. Tighten the cable nuts, ensure that the cable nuts are securely tightened to each other for each cable.
5. Adjust the clearance between the column and cross beam slide block (generally 2mm), and then tighten the slide block with bolt.
6. After finishing the above adjustment, test running the lift with load. Run the lift with Platforms in low position first, make sure the Platforms can rise and lower synchronously and the Safety Device can lock and release synchronously. And then test run the lift to the top completely. If there are anything improper, repeat the above adjustment.



**Fig. 56**

## VI. OPERATION INSTRUCTIONS

### To lift vehicle

1. Keep clean of environment near the lift;
2. Ensure the air source switch is activated, drive vehicle to the platform and apply the brake.
3. Turn on the power and press the button **UP**, raise the lift to the working position;  
**Note: make sure the vehicle is steady when the lift is raised.**
4. Press the Handle of release valve to lock the lift in the safety position. Make sure the Safety devices are locked at the same height.



**WARNING** It is unsafe to work under the lift without locking at the safety device after it has been lifted up, which may causes vehicle fall, damage, lift damage, human injury or even death.

### To lower vehicle

1. Clear obstructions around and under the lift, make sure to move away the people around.;
2. Ensure the air source switch is activated, Press the button **UP**, the lift will be raised for 3-5 seconds, and then press the button of Manual-controlled air valve to release the safety devices, then press the handle of release valve by the other hand then the lift starts being lowered automatically;
3. Drive away the vehicle when the lift is lowered to the lowest position.
4. Turn off the power.

## VII. MAINTENANCE SCHEDULE

### Monthly:

1. Re-torque the anchor bolts to 150 Nm;
2. Lubricate cable with lubricant;
3. Check all cable connection, bolts and pins to insure proper mounting;
4. Make a visual inspection of all hydraulic hoses/lines for possible wear or leakage;
5. Lubricate all Rollers, Safety devices with 90wt. gear oil or equivalent.

**Note: All anchor bolts should take full torque. If any of the bolts does not function for any reason, DO NOT use the lift until the bolt has been replaced.**

### **Every six months:**

1. Make a visual inspection of all moving parts for possible wear, interference or damage.
2. Check and adjust as necessary, equalizer tension to insure level lifting.
3. Check columns for plumbness.

### **Oil cylinder maintenance:**

In order to extend the service life of the oil cylinder, please operate according to the following requirements.

1. Recommend to use N46 anti-wear hydraulic oil.
2. The hydraulic oil of the lifts should be replaced regularly during using.  
Replace the hydraulic oil 3 months after the first installation, Replace the hydraulic oil once a year afterwards.
3. Make at least one full trip raising and lowering per day. For exhausting the air from the system, which could effectively avoid the corrosion of the cylinder and damage to the seals caused by presence of air or water in the system.
4. Protect the outer surface of the oil cylinder's piston rod from bumping and scratching, and timely clean up the debris on the oil cylinder dust-ring and the piston rod.



**DANGER** Make sure the lift is completed disconnected from the power source before maintenance. If there is any external electrical lock/shutdown device, make sure to implement them before maintenance. The contact with high voltage/current, may cause injury or even death.

## VIII. TROUBLE SHOOTING

TROUBLE	CAUSE	REMEDY
Motor does not run	1. Start Button does not work 2. Wiring connections are not in good condition 3. Motor burned out 4. AC contactor burned out 5. Height limit switch is damaged	1. Replace Start button 2. Repair all wiring connections 3. Repair or replace motor 4. Replace AC contactor 5. Replace
Motor runs but the lift is not raised	1. Motor runs in reverse rotation 2. Release valve in damage 3. Gear pump in damage 4. Relief valve or check valve in damage 5. Low oil level	1. Reverse two power wire 2. Repair or replace 3. Repair or replace 4. Repair or replace 5. Fill tank
Lift does not stay up	1. Release valve out of work 2. Relief valve or check valve leakage. 3. Cylinder or fittings leaks	Repair or replace
Lift raises too slow	1. Oil line is jammed 2. Motor running on low voltage 3. Oil mixed with Air 4. Pump leaks 5. Overload lifting	1. Clean the oil line 2. Check electrical system 3. Fill tank 4. Replace Pump 5. Check load
Lift cannot lower	1. Safety device are in activated 2. Release valve damaged 3. Air Cylinder damaged 4. Oil system is jammed	1. Release the safeties 2. Replace or repair 3. Replace the cylinder 4. Clean the oil system



**WARNING** A lift would be dangerous if operated by inexperienced or distracted operators. Operators should be fully aware that lifting a vehicle is a potentially life-threatening operation, especially if ignoring the mandatory safety precautions.

## **IX. CAR LIFT SAFETY TIPS**

Put this safety tips in a place where you can always alert the operator. Please reference to the lift manufacturer's manual for specific information about the lift.

1. Check the lift daily. If the machine breaks down or has damaged parts, do not operate, and use original equipment parts to repair.
2. **Do not** overload . The rated weight of the manufacturer design is indicated on the label of the lift.
3. Position control of the vehicle and operation of the lift can only be done by a trained and authorized person.
4. **Do not** lift a car with occupants inside. Keep the customers or bystanders away from the lift.
5. Keep the area around the lift free of obstacles, lubricating oil, grease, garbage and other debris for a long time.
6. Carefully drive the vehicle onto the lift and lifting up to the required height for operation. **Noted:** lift it high enough if you are working underneath, and make sure the safety devices are locked.
7. **Noted:** removing( install) parts from(to) a vehicle would cause a sudden shift of gravity which may result in instability of the vehicle. Please refer to the vehicle manufacturer's service manual as a recommended procedure if you need remove/install parts from(to) the vehicle
8. Before lowering the lift , make sure all obstacles underneath, include tool tray, tool rack etc., are all removed.

## **IIX. LIFT DISPOSAL**

When the car lift cannot meet the requirements for normal use and needs to be disposed, it should follow local laws and regulations.

**Address:**

SC Division: 1931 Joe Rogers Jr Blvd, Manning, SC 29102, USA  
TX Division: 4310 Adler Dr., Suite #200, Dallas, TX 75211, USA

<http://www.amgohyd.com>